

# 22. TROUBLESHOOTING

|  |             |                                       |             |
|--|-------------|---------------------------------------|-------------|
| <b>ENGINE DOES NOT START OR IS HARD TO START</b> | <b>22-1</b> | <b>POOR PERFORMANCE AT HIGH SPEED</b> | <b>22-4</b> |
| <b>ENGINE LACKS POWER</b>                        | <b>22-2</b> | <b>POOR HANDLING</b>                  | <b>22-4</b> |
| <b>POOR PERFORMANCE AT LOW AND IDLE SPEED</b>    | <b>22-3</b> |                                       |             |

## ENGINE DOES NOT START OR IS HARD TO START

### Possible cause

