

## ALTERNATOR/STARTER CLUTCH

---

Connect the alternator 3P (White) connector.

Install the air cleaner housing (page 5-5).  
Add the recommended oil up to proper level (page 3-12).

