

Maintenance Schedule

Perform the PRE-RIDE INSPECTION in the Owner's Manual at each scheduled maintenance period.

I: Inspect and clean, Adjust, Lubricate or Replace if necessary.

R: Replace, C: Clean, L: Lubricate, A: Adjust

The following items require some mechanical knowledge. Certain Items (particularly those marked *and**) may require more technical information and tools. Consult your authorized Honda dealer.

Item	Frequency	Whichever comes first Note	Odometer Reading (Note 1)						Refer To Page		
			× 1,000 km	1	6	12	18	24		30	36
			× 1,000 mi	0.6	4	8	12	16		20	24
			Months		6	12	18	24	30	36	
• Fuel Line					I		I		I	Note 6	
• Fuel Strainer Screen				C	C	C	C	C	C	Note 6	
• Throttle Operation					I		I		I	Note 6	
• Carburetor Choke					I		I		I	Note 6	
Air Cleaner		Note 2					R		R	3-5	
Crankcase Breather		Note 3		C	C	C	C	C	C	Note 6	
Spark Plug				I	R	I	R	I	R	Note 7	
Engine Oil			R	R	R	R	R	R	R	Note 7	
Engine Oil Filter			R		R		R		R	Note 6	
• Carburetor Synchronization					I		I		I	3-5	
• Carburetor Idle Speed			I	I	I	I	I	I	I	Note 7	
• Secondary Air Supply System		Note 4			I		I		I	Note 6	
• Drive Chain			Every 1,000 km (600 mi) I, L						Note 6		
• Drive Chain Slider					I		I		I	3-6	
• Battery				I	I	I	I	I	I	Note 6	
Brake Fluid		Note 5		I	I	R	I	I	R	Note 7	
Brake Pad Wear				I	I	I	I	I	I	Note 6	
Brake System			I		I		I		I	Note 6	
• Brake Light Switch					I		I		I	Note 6	
• Headlight Aim					I		I		I	Note 6	
Clutch System			I	I	I	I	I	I	I	Note 6	
Side Stand					I		I		I	Note 6	
• Suspension					I		I		I	Note 6	
• Nuts, Bolts, Fasteners			I		I		I		I	1-14	
• • Wheels/Tires					I		I		I	Note 6	
• • Steering Head Bearings			I		I		I		I	Note 6	

- Should be serviced by an authorized Honda dealer, unless the owner has the proper tools and service data, and is mechanically qualified. Refer to the official Honda service Manual.
- • In the interest of safety, we recommended these items be serviced only by an authorized Honda dealer.

- Notes:
1. At higher odometer readings, repeat at the frequency interval established here.
 2. Service more frequently when riding in unusually wet or dusty areas.
 3. Service more frequently when riding in rain or at full throttle.
 4. Switzerland and Austria type only.
 5. Replace every 2 years, or at indicated odometer interval, whichever comes first. Replacement requires mechanical skill.
 6. Refer to the Common Service Manual.
 7. Use the specifications in section one and refer to the Common Service Manual.