

Drive Chain Slider

Check the drive chain slider for wear.
Replace the drive chain slider if it is worn to wear index mark.

CAUTION

- If the chain slider becomes worn through to the swingarm, the chain will begin to wear against the swingarm.

Remove the swingarm and replace the drive chain slider (page 11-11).

