


INSTALLATION

Install the new gasket onto the cam chain tensioner lifter.
Install the cam chain tensioner lifter into the cylinder head.



Install and tighten the mounting bolts securely.

Remove the stopper tool.

Install a new sealing washer and tighten the sealing bolt securely.

Install the removed parts in the reverse order of removal.

