












# CYLINDER HEAD/VALVES

## TOOLS

<p>Tensioner lifter stopper 070MG-0010100</p> 	<p>Valve spring compressor 07757-0010000</p> 	<p>Valve guide reamer, 5.0 mm 07984-MA60001</p> 
<p>Valve guide driver, 5.0 mm 07942-MA60000</p> 	<p>Valve guide adjusting driver 07743-0020000</p> 	<p>Seat cutter, 27.5 mm (IN, 45°) 07780-0010200</p> 
<p>Seat cutter, 24 mm (EX, 45°) 07780-0010600</p> 	<p>Flat cutter, 27 mm (IN, 32°) 07780-0013300</p> 	<p>Flat cutter, 22 mm (EX, 32°) 07780-0012601</p> 
<p>Interior cutter, 26 mm (IN, 60°) 07780-0014500</p> 	<p>Interior cutter, 22 mm (EX, 60°) 07780-0014202</p> 	<p>Cutter holder 5.0 mm 07781-0010400</p> 