












# FRONT WHEEL/SUSPENSION/STEERING

## TOOLS

<p>Bearing remover shaft 07746-0050100</p> 	<p>Bearing remover head, 12 mm 07746-0050300</p> 	<p>Driver 07749-0010000</p> 
<p>Attachment, 32 x 35 mm 07746-0010100</p> 	<p>Pilot, 12 mm 07746-0040200</p> 	<p>Oil seal remover 07748-0010001</p> 
<p>Fork seal driver body 07747-0010100</p> 	<p>Fork seal driver attachment 07747-0010400</p> 	<p>Socket wrench 07916-KM10000</p> 
<p>Adjusting nut wrench 07SMA-GBC0100</p> 	<p>Inner driver, 30 mm 07746-0030300</p> 	<p>Adjustable remover head 07JAC-PH80100</p> 