

## ELECTRIC STARTER

### RELAY INSPECTION

Remove the inhibitor relay (page 20-13).

Connect the ohmmeter to the following inhibitor relay terminals.

**Connection: A – B**

Connect the 12 V battery to the following inhibitor relay terminals.

**Connection: C – D**

There should be continuity between the relay terminals while the battery is connected, and no continuity when the battery is disconnected.

