
POOR HANDLING

Steering is heavy

- Steering stem adjusting nut too tight
- Damaged steering head bearings
- Low tire pressure

Either wheel is wobbling

- Excessive wheel bearing play
- Faulty tire
- Bent rim
- Excessively worn engine mounting bushings
- Bent frame

The scooter pulls to one side

- Front and rear wheels not aligned
- Faulty shock absorber
- Bent fork
- Bent axle
- Bent frame